





Large, clear LCD display

The thermometer can easily be changed from degree Celsius (°C) to degree Fahrenheit (°F) by pressing the pick hole on the back side with a pointed object

Nylon wrist strap included

BATTERY REPLACEMENT: A flashing battery icon in the LCD indicates a low battery. To replace a low battery, confirm that the unit power is OFF, loosen the screw on the back cover and replace both of the old batteries. The Zilla Digital Infrared Thermometer requires two (2) LR44 1.5V cell batteries.

 $\ensuremath{\mathsf{NOTE}}\xspace$: Dispose of all unused batteries properly and keep all batteries away from children.

DIGITAL INFRARED THERMOMETER						
	ITEM NO.	UPC NO.	RETAIL PACKAGE SIZE L x W x H	CASE CODE	CASE SIZE L x W x H	CASE QTY.
Digital Infrared Thermometer	09790	096316680319	3.625" x 1.125" x 6"	10096316680316	12.5" x 11" x 13.5"	60